


# INSTALLATION OPERATION AND SERVICE MANUAL

## Grate Fires Ventfree Fireplace Assemblage

### MODELS

WR9001 GV30 -WR4001 BV30N  
WR9001 BRGV30 - WR4001 BV30N

WR9901GV36F - WR4001 BV30N  
WR9901 BRGV36F - WR4001 BV30N



**PLEASE READ THIS MANUAL CAREFULLY BEFORE INSTALLING AND OPERATING THE APPLIANCE.**

**INSTALLER: Leave this manual with the appliance.  
CONSUMER: Retain this manual for future reference.**

**WARNING: If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.**

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance

#### WHAT TO DO IF YOU SMELL GAS:

- \*Do not try to light any appliance.
- \*Do not touch any electrical switch; do not use any phone in your building.
- \*Immediately call your gas supplier from a neighbors phone. Follow the gas suppliers instructions.
- \*If you cannot reach your gas supplier; call the fire department.

- Installation and service must be performed by a qualified installer, service agency or the gas supplier.

This is an unvented gas fired heater. It uses air (oxygen) from the room in which it is installed. Provisions for adequate combustion and ventilation air must be provided. See Section 2

**WARNING: This appliance is equipped for Natural Gas. Field conversion is not permitted.**

Grate Fires

P.O. Box 400 \* Washington, Georgia 30673 \* (PH) 706-678-5459 (FAX) 706-678-5470

Email: [coal@nu-z.net](mailto:coal@nu-z.net) Web site: [www.gratefires.com](http://www.gratefires.com)

